



Connection Details for:

**Live-Link™ Camera End Unit
(Order Codes: LL-3G-CA-031 and LL-3G-CA-032)**


**Live-Link Control Room Unit
(Order Codes: LL-3G-CR-031 and LL-3G-CR-032)**

and Model 36 Talent Interface


Live-Link – Camera End Unit

Order Codes: LL-3G-CA-031 and LL-3G-CA-032

3G Digital Video, Four Mic/Line Inputs,
Two Line Output, One IFB Output, 4-Wire Intercom
Neutrik opticalCON® QUAD



Mic/Line Inputs 1-4



Line Outputs 1-2


Live-Link – Camera End Unit, continued

Order Codes: LL-3G-CA-031 and LL-3G-CA-032

3G Digital Video, Four Mic/Line Inputs,
Two Line Output, One IFB Output, 4-Wire Intercom
Neutrik opticalCON® QUAD



IFB Output




4-Wire Intercom


Live-Link – Control Room Unit

Order Codes: LL-3G-CR-031 and LL-3G-CR-032

3G Digital Video, Mic/Line Outputs,
Two Line/IFB Inputs, 4-Wire Intercom
Neutrik opticalCON® QUAD



To 4-Wire Intercom




From 4-Wire Intercom


Live-Link – Control Room Unit, continued

Order Codes: LL-3G-CR-031 and LL-3G-CR-032

3G Digital Video, Mic/Line Outputs,
Two Line/IFB Inputs, 4-Wire Intercom
Neutrik opticalCON® QUAD




Line/IFB Inputs 1-2




Mic/Line Outputs 1/2, 3/4

Model 36 Talent Interface

Mic Input, To/From I/O, Headset, Headphone Outputs




Mic Input




To/From I/O

Model 36 Talent Interface, continued

Mic Input, To/From I/O, Headset, Headphone Outputs



Model 36-5 Headset Connector (5-Pin)



Model 36-6 Headset Connector (6-Pin)

Model 36 Talent Interface, continued

Mic Input, To/From I/O, Headset, Headphone Outputs



Model 36-7 Headset Connector (7-Pin)



Headphone Outputs